


Android



Go to the Android Market find:
Ip Cam Viewer by Robert Chou

There is two free versions:

- Basic or Lite, both works the same up to 6 cameras.
- Pro, the paid version will give you 16 camera view.
- Install the program and go to Manage Cameras
- Delete the the existing demo cameras one by one
- Add cameras
 - Name: Anything can be here
 - Make: ADT
 - Model: ADT DYK4500
 - Host/IP: Your LAN or WAN address
(port needs to be opened for WAN in the Router)
 - HTTP Port: Default 80 in the DVR
(has to be the same as DVR if changed)
 - Ch.#: Camera number
 - User: Same as DVR
 - PW: Same as DVR

Hit TEST if it says OK then click Save and move on to set up the next camera.

